## KG6SII's AREDN firmware loading issues – 4/10/22

Errors I get when trying to flash 3.22.1.0 onto a Ubiquity Rocket M5 and Ubiquity NanoStation M5:

- On both of my Windows 10 computers: "Connect Request Failed"
- On my old Windows XP computer: "Firmware check failed" or it just sits forever

Things I've tried so far to fix this:

- Used a cable tester on all my cables, found 1 cable with a bad connection on pin 8, stopped using that cable
- Got a 10/100 switch
- Got a PoE injector from Amazon (non-Ubiquity brand, this is last in line after the 10/100 switch, before the radio)
- Tried loading all available firmware files (-m, -xw, etc., unplugging everything in between each attempt, re-doing the radio reset sequence)
- Pings now report fine: 4/4, 0% loss, 0ms
- The radios have an old Ubiquity AirOS loaded on them (v6.3.6 XW). See existing firmware settings below for the Rocket:

977L - Google Drive 28 N2977L Cale	ndar 🛛 🖉 Civil Air Patrol eServic	, 🛛 🖓 Fidelity N	etBenefits	🙀 Personal We	ather Stati	🚽 Airport Det	ail: KPRB   L	My Esri   Product Infor	SkyVector: Flight
	rock	<b>4167 1</b> M5							aiṙ̀0S <sup>∞</sup>
	24	MAIN	WIRELESS	NETWORK	ADVANCED	SERVICES	SYSTEM	UNMS Tools:	✓ Logout
	airMAX	Settings:				airView			
		airMAX Priority:	[?] Base		•)	P. L	airView Port: aunch airView		
			2						Change

×	MAIN	VIRELESS	NETWORK	ADVANCED	SERVICES	SYSTEM	• UNMS" Tools:	Y L
tatus								
	Device Model	Rocket M5				CPU:		3 %
	Device Name:	Rocket M5				Memory:	調査主要語	33 %
	Network Mode:	Bridge						
	Wireless Mode:	Station					Not Associated	
	SSID:	ubnt				Signal Strength:		
	Security	none				Chain0 / Chain1: Noise Floor:		
		v6.3.6 (XV	0			Transmit CCQ:		
		00:03:11				TX/RX Rate:		
	Date:	2021-08-1	8 19:33:06					
Ch	annel/Frequency:	164 / 5820	MHz			airMAX:	87	
	Channel Width:	20 MHz				UNMS: [?]	Disabled	
	Frequency Band	5810 - 583	0 MHz					
		0.7 miles (	1.1 km)					
	TX/RX Chains:							
	TX Power:							
	Antenna:	RD-5G-34	- 34 dBi					
	WLAN0 MAC:	44:D9:E7:D	A:B3:74					
	LAN0 MAC:	44:D9:E7:D	B:B3:74					
	LAN0:	100Mbps-F	Full					
onitor								
	Throughpu	It AP Inform	nation   Inter	faces   DHCP C	lient   ARP Tab	le   Bridge Table	Routes   Firewall   Log	ļ
		LAN0						
20								
17.5	RX: 3.60kbps							
12.5	TX: 11.9kbps							
10								
7.5								
5								
2.5								
kbps 0								

main w	/IRELESS	NETWORK	ADVANCED	SERVICES	SYSTEM	UNMS Tools:	
Basic Wireless Settings							
Wireless	s Mode: 🚺	Station	~]				
WDS (Transparent Bridge	Mode): [	Enable	~~~				
	SSID: U	ibnt	S	ielect			
Lock	k to AP:						
Country	y Code: [	United States					
IEEE 802.11	1 Mode: 🕢	A/N mixed					
Channel W	/idth:[?]	Auto 20/40 MHz	<b>v</b> )				
Frequency Scan Lis	st, MHz: [	Enable					
Calculate EIR	१P Limit: 📲	Enable					
Ar	ntenna: [	RD-5G-34 (2x2) - 34	dBi 🗸				
Output F	Power:	c	- 8	dBm			
Data Rate N	Module:	Default	~				
Max TX Rate,	, Mbps: []	MCS 15 - 130/144.4	[270 🗸 🔽	Auto			
Wireless Security							
Se	ecurity:	none	~				
							Change

The second se	MAIN WIREL	ESS NETWORK	ADVANCED	SERVICES	SYSTEM	• UNMS" Tools:	v L
				521171525	Croren		
Network	Role						
	Network Mod	e: Bridge	~				
	Disable Networ	k: None	~				
] Configura	ition Mode						
	Configuration Mod	Simple	~				
	ent Network Settin anagement IP Addres		tic		IPv6	Enable	
	DHCP Fallback I	P: 192.168.1.20			IPv6 Address	O Static 💿 SLAAC	
1	HCP Fallback Netmas	c 255.255.255.0					
		J: 1500					
	Management VLA						
	Auto IP Aliasin	All and a second second					
	ST	P: 🔲 Enable					

The	MAIN	WIRELESS	NETWORK	ADVANCI	ED SEF	RVICES	YSTEM	UNMS" Too	ols:	✓ Logo
Advance	d Wireless Se	ettings								
	RTS T	hreshold: [?] 234	16 🔽 Off							
	1	Distance: [?]			0.4	miles (0.6 km)	🔽 Auto Adjus	ŧ		
	Agg	gregation: [?] 32	Frames	50000	Bytes	🗸 Enable				
	Multic	ast Data: [?] 🔽	Allow							
	Installer EIR	P Control: [?]	Enable							
	Extra R	Reporting: [?] 🔽	Enable							
Se	ensitivity Thresh	old, dBm: [?] -96	🔽 Off							
Muanco	d Ethernet Se	ttings								
Anvance		<u>0,111) - 111 - 11</u>								
Auvancei	EAN	0 Secol: (2) 10	100 Auto	10.01						
Auvances	LAN	10 Speed: [?] 10	'100 Auto	× )						
	LAN D Thresholds		100 Auto	~						
94. in strate in the		i			LEDA					
94. in strate in the	D Thresholds	i	ED1 LED2	LED3	LED4					
94. in strate in the	D Thresholds	; 	ED1 LED2	LED3	1220 C 1220					

2K	MAIN	RELESS	NETWORK	ADVA	NCED	SERVICES SYSTEM	INMS) Tools: V Log		
Ubiquiti Net	work Manageme	nt Syste	m						
	UN	MS: 🔲	Enable						
		Url: -							
		Key: Edit							
Ping Watch	dog					SNMP Agent			
	22 10 10		25 704				<b>—</b> • •		
	Ping Watch	Star games	Enable		-1	SNMP Agent:			
	IP Address To I	Sector Sector				SNMP Community:	public		
	o seprembra da la	val: 300	seconds			Contact:	· · · · · · · · · · · · · · · · · · ·		
E.	Startup De ailure Count To Reb		seconds			Location:			
0.63	Save Support								
	oure oupput								
Neb Server						SSH Server			
	Web Ser	ver: 🔽	Enable			SSH Server:	C Enable		
Secu	re Connection (HTT					Server Port:			
	Secure Server					Password Authentication:			
	Server	Port: 80	-			Authorized Keys:	Edit		
	Session Time	out: 15	minutes						
Telnet Servi						NTP Client			
remet servi	61					NTP Client			
	Telnet Ser	ver: 🔲	Enable			NTP Client:	Enable		
	Server	Port: 23				NTP Server:	0.ubnt.pool.ntp.org		
Dynamic DN	IS					System Log			
	Dynamic I	10110				System Log:			
		ice: dyn	dns.org	×		Remote Log:	L Enable		
	Host N					Remote Log IP Address:			
	User N	0.04				Remote Log Port:	Proceeding Walter		
Device Disc	Passw overy	ord:			Show	TCP Protocol:			
and a crane of									
	Discov	ery: 🔽	Enable						

	et M5								
×	MAIN WI	RELESS	NETWORK	ADVANCED	SERVICES	SYSTEM	UNMS Tools:		~ Log
Firmware	Update								
	Firmware Ver	sion: XW.	v6.3.6		Upload Fir	rmware: (	Browse No file selected.		
	Build Nun		100 g						
	Check for Upda	ates: 🗹	Enable Check I	Now					
Device					Date Settings				
	Device N	ame: Roo	sket M5		Tim	ne Zone: (	(UTC/GMT) Universal Tim 🗸	J	
	Interface Langu	age: Eng	glish	<b>v</b> )	Start	up Date:	Enable		
	FC	C ID: SW	X-R5M		Start	up Date:			
System A	ccounts								
		1.00							
	Administrator User N			9					
	Read-Only Acc	ount: 📋	Enable						
Miscellan	eous				Location				
	Reset Buttor	ı: [?] 🔽	Enable		I	Latitude:			
	Revised UNII Rules	s: [ <b>?]</b> De	activate		Lo	ongitude: [			
								(	Change
Device M	aintenance				Configuration M	anadom	ent		
e e rrose inte						anagem			
	Reboot De	vice:	Reboot		Back Up Config	guration: (	Download		
	Support	Info: De	ownload		Upload Config	guration: (	Browse No file selected.		
					Reset to Factory D	Defaults:	Reset		